

# Clamp Multimeters

UT 201



UT 206



**UNI-T**

**Function**

	<b>UT 201</b>	<b>UT 206</b>
<b>Indicating Range</b>	1 999	3 999
<b>Accuracy</b>	0,8% - 1,5%	0,8% - 1,5%
<b>Voltage AC</b>	2 V - 600 V	4 V - 600 V
<b>Voltage DC</b>	0,2 V - 600 V	0,4 V - 600 V
<b>Current AC</b>	2 A - 400 A	to 1000 A
<b>Current DC</b>	-	-
<b>Resistance</b>	200 Ω - 20 MΩ	400 Ω - 40 MΩ
<b>Continuity Test</b>	yes	yes
	<50 Ω buzzer	
<b>Frequency</b>	-	10 Hz - 10 MHz
<b>Capacitance</b>	-	4 nF - 200 uF
<b>Temperature</b>	-	-40°C to +1000°C
<b>Data Hold</b>	yes	yes
<b>Max. Clamp Opening</b>	40 mm	40 mm
<b>Notes</b>	diode test Battery power supply 2xAAA	diode test Battery power supply 9V + 2xAAA Display Backlight

**Part No.**      **Ord.No.**

S UT 201	48193
S UT 206	42543

MS 2102



DT 266



CHEAP



**Function**

	<b>MS 2102</b>	<b>DT 266</b>
<b>Indicating Range</b>	3 999	LCD 3 1/2
<b>Accuracy</b>	1% - 2,5%	2%
<b>Voltage AC</b>	do 600 V	1V - 750V
<b>Voltage DC</b>	do 600 V	1V - 1000V
<b>Current AC</b>	do 400 A	0,1A - 1000A
<b>Current DC</b>	do 400 A	
<b>Resistance</b>	do 400 Ω	100mΩ - 20kΩ
<b>Continuity Test</b>	yes	yes
<b>Frequency</b>	-	
<b>HOLD</b>	yes	yes
<b>Max. Clamp Opening</b>	28 mm	50 mm
<b>Notes</b>	analog bargraph case bag	-

**Part No.**      **Ord.No.**

S MS 2102	47507
S DT 266	57525

UT 232



CAT III 600V

UT232 can measure power from one to three phases like an active energy counter up to 9999kWh. To minimize the amount of interference created by engineers in the operation of machines, a test device is required that can measure voltage, current and power (Active, Apparent, Reactive power), power factor USB Interface

**UNI-T**

**Function**

	<b>UT 232</b>
<b>Indicating Range</b>	9999
<b>Accuracy</b>	0,5% - 3%
<b>Voltage AC</b>	20 V - 600 V
<b>Voltage DC</b>	-
<b>Current AC</b>	40 A - 1000 A
<b>Current DC</b>	-
<b>Reactive Power</b>	0,60 kVar - 600,0 kVar
<b>Apparent Power</b>	0,60 kVA - 600,0 kVA
<b>Active Power</b>	0,60 kW - 600,0 kW
<b>Power Factor (<math>\cos \varphi</math>)</b>	0,3-1
<b>Phase Angle</b>	0-360°
<b>Frequency</b>	20Hz - 500 Hz
<b>Active Energy (KWh counter)</b>	0 - 9999kWh

**Part No.**      **Ord.No.**

S UT 232	59923
----------	-------

VA 315



NEW!

VA 316



**V&A**  
INSTRUMENT

**Function**

	<b>VA 315</b>	<b>VA 316</b>
<b>Indicating Range</b>	5999	
<b>Accuracy</b>	0,1% - 5%	0,1% - 8%
<b>Voltage AC</b>	6 V - 700 V	4 V - 700 V
<b>Voltage DC</b>	6 V - 1000 V	0,4 V - 700 V
<b>Current AC</b>	to 1000 A	to 1000 A
<b>Current DC</b>	-	to 1000 A
<b>Resistance</b>	600 Ω - 60 MΩ	400 Ω - 40 MΩ
<b>Continuity Test</b>	yes, buzzer	yes, buzzer
<b>Frequency</b>	40 Hz - 100 kHz	10 Hz - 200 kHz
<b>Capacitance</b>	600 nF - 1000 uF	4 nF - 40 uF
<b>ADP Measurement</b>	600 mV	-
<b>Temperature</b>		-40°C to + 750°C
<b>Notes</b>	diode test, auto/manual range, MAX/MIN, data hold, Back Light	

**Part No.**      **Ord.No.**

S VA315	59457
S VA316	67608